

TRV-2, TRV-2S

Thermostatic radiator valves with presetting



HEIMEIER

Pressurisation & Water Quality › Balancing & Control › Thermostatic Control

ENGINEERING ADVANTAGE

Thermostatic radiator valve primary for radiators in heating systems and secondary for small cooling terminals.

> **Stepless presetting**

Accurate balancing.

> **Max Δp 30 kPa**

Better comfort.

> **Double O-rings**

Trouble free operation.



> Technical description

Applications:

Heating and cooling systems

Function:

Control
Stepless presetting
Shut-off

Dimensions:

DN 10-20

Pressure class:

PN 10

Max. differential pressure:

Maximum differential pressure to ensure that the valve does not open against a closed thermostat: 100 kPa.

Temperature:

Max. working temperature: 120°C
Min. working temperature: -10°C

Materials:

Valve body: Straight and angle of AMETAL®. Reversed angle of brass.
O-rings: EPDM rubber
Valve disc: EPDM rubber
Return spring: Stainless steel
Valve insert: Brass, PPS (polyphenylsulphide)
Spindle: Stainless steel

AMETAL® is the dezincification resistant alloy of TA.

Surface treatment:

Valve body and fittings are nickel-plated

Marking:

TA, country code, flow direction arrow, size and KEYMARK symbol.
TRV-2: White protection cap.
TRV-2S: Red protection cap. The locking nut at the valve insert is marked in red.

Standards:

KEYMARK certified and tested to EN 215.




026

Connection to thermostatic head:

M30x1.5

Operating instruction



The valve is supplied with a protective wheel. The protective wheel can easily be replaced by a handwheel, thermostatic head or an actuator. If the protective wheel is used to isolate when dismantling the radiator, the outlet must be plugged or capped.

Attention! TRV-2/TRV-2S requires clean system water to work properly without disturbance because of clogging.


Noise

The following conditions must be fulfilled in order to avoid noise in the heating system:

- Flows correctly balanced
- The water in the system must have been de-aerated
- Circulation pumps which do not give too high differential pressure (alternative use a differential pressure controller, e.g. STAP).

The maximum recommended pressure drop in order to avoid noise: 30 kPa = 0,3 bar.

Setting




The valve has stepless pre-setting which can be adjusted by the pre-setting tool.

The valve is delivered with the pre-setting of 6, i.e. fully open valve.

1. Remove the protective wheel.
2. Set the required value using the pre-setting tool (Article No 50 198-004).
3. Refit the protective wheel (alternatively the thermostat head or the handwheel).

Diagram TRV-2 Straight and angle

(KvΔT2K)




Pre-setting value	1	1.5	2	2.5	3	3.5	4	4.5	5	5.5	6
KvΔT2K*	0,047	0,073	0,098	0,130	0,161	0,198	0,234	0,299	0,364	0,416	0,468
Fully open valve disc**	0,054	0,079	0,104	0,139	0,174	0,211	0,247	0,353	0,459	0,630	0,800***

*) The values are valid when used together with thermostic head TRV 300.

**) The values are valid for on/off regulation with, for example, thermo actuator EMO T.

***) Fully open valve.

Diagram TRV-2 Reversed angle

(Kv Δ T2K)

Pre-setting value	1	1.5	2	2.5	3	3.5	4	4.5	5	5.5	6
Kv Δ T2K*	0,063	0,089	0,095	0,120	0,152	0,171	0,206	0,281	0,348	0,421	0,462
Fully open valve disc**	0,063	0,089	0,095	0,123	0,158	0,180	0,221	0,323	0,430	0,626	0,727***


*) The values are valid when used together with thermostic head TRV 300.

**) The values are valid for on/off regulation with, for example, thermo actuator EMO T.

***) Fully open valve.

Diagram TRV-2S Low flow

(KvΔT2K)




Pre-setting value	1	1.5	2	2.5	3	3.5	4	4.5	5	5.5	6
KvΔT2K*	0,017	0,022	0,041	0,047	0,063	0,075	0,111	0,142	0,177	0,228	0,316
Fully open valve disc**	0,017	0,022	0,041	0,047	0,063	0,078	0,114	0,150	0,187	0,240	0,350***

*) The values are valid when used together with thermostic head TRV 300.

**) The values are valid for on/off regulation with, for example, thermo actuator EMO T.

***) Fully open valve.

Excluding radiator union




Straight

Article No	EAN	DN	D	Da	L	H1	H2*	Kv Δ T2K
50 861-610	7318793757500	10	G3/8	M22x1,5	50	36	107	0,047-0,468
50 861-615	7318793757609	15	G1/2	M26x1,5	58	38	109	0,047-0,468
50 861-620	7318793757708	20	G3/4	M34x1,5	68	38	109	0,047-0,468

TRV-2S, low flow

Article No	EAN	DN	D	Da	L	H1	H2*	Kv Δ T2K
50 861-010	7318793788009	10	G3/8	M22x1,5	50	36	107	0,017-0,316
50 861-015	7318793788108	15	G1/2	M26x1,5	58	38	109	0,017-0,316
50 861-020	7318793788207	20	G3/4	M34x1,5	68	38	109	0,017-0,316

Angle




Article No	EAN	DN	D	Da	L	H	H1	H2*	Kv Δ T2K
50 863-610	7318793758309	10	G3/8	M22x1,5	23	20	36	107	0,047-0,468
50 863-615	7318793758408	15	G1/2	M26x1,5	26	24	38	109	0,047-0,468
50 863-620	7318793758507	20	G3/4	M34x1,5	31	28	36	107	0,047-0,468

TRV-2S, low flow

Article No	EAN	DN	D	Da	L	H	H1	H2*	Kv Δ T2K
50 863-010	7318793946805	10	G3/8	M22x1,5	23	20	36	107	0,017-0,316
50 863-015	7318793946904	15	G1/2	M26x1,5	26	24	38	109	0,017-0,316
50 863-020	7318793947000	20	G3/4	M34x1,5	31	28	36	107	0,017-0,316

Reversed angle



Article No	EAN	DN	D	Da	L	H	H1	H2*	Kv Δ T2K
50 864-610	7318793759009	10	G3/8	M22x1,5	23	21	47	119	0,063-0,462
50 864-615	7318793759108	15	G1/2	M26x1,5	26	25	47	119	0,063-0,462

TRV-2S, low flow

Article No	EAN	DN	D	Da	L	H	H1	H2*	Kv Δ T2K
50 864-010	7318793787606	10	G3/8	M22x1,5	23	21	47	119	0,017-0,316
50 864-015	7318793787705	15	G1/2	M26x1,5	26	25	47	119	0,017-0,316

*) Valve with fitted thermostat.

$K_v = m^3/h$ at $\Delta p = 1$ bar.


$K_v\Delta T2K$ = The values are valid when used together with thermostatic head TRV 300.

All valves can be connected to smooth pipes by means of the KOMBI compression coupling - See catalogue leaflet KOMBI.

Angle

For replacement of radiator valve in manifold assemblies.


TRV-2S, low flow



Article No	EAN	DN	D	Da	L	H	H1	H2*	KvΔT2K
50 864-210	7318793947703	10	G3/8	M22x1,5	27	46,5	37	108	0,017-0,316

Including radiator union

Straight




Article No	EAN	DN	d	D	Da	L	H1	H2*	KvΔT2K
50 861-110	7318793757807	10	R3/8	G3/8	M22x1,5	75	36	107	0,047-0,468
50 861-115	7318793757906	15	R1/2	G1/2	M26x1,5	88	38	109	0,047-0,468
50 861-120	7318793758002	20	R3/4	G3/4	M34x1,5	102	38	109	0,047-0,468

TRV-2S, low flow


Article No	EAN	DN	d	D	Da	L	H1	H2*	KvΔT2K
50 861-510	7318793788306	10	R3/8	G3/8	M22x1,5	75	36	107	0,017-0,316
50 861-515	7318793788405	15	R1/2	G1/2	M26x1,5	88	38	109	0,017-0,316

Straight



Article No	EAN	DN	d	D	Da	L	H	H1	H2*	KvΔT2K
50 862-110	7318793758101	10	R3/8	G3/8	M22x1,5	93	46	36	107	0,047-0,468
50 862-115	7318793758200	15	R1/2	G1/2	M26x1,5	106	52	38	109	0,047-0,468

Angle



Article No	EAN	DN	d	D	Da	L	H	H1	H2*	KvΔT2K
50 863-110	7318793758606	10	R3/8	G3/8	M22x1,5	48	20	36	107	0,047-0,468
50 863-115	7318793758705	15	R1/2	G1/2	M26x1,5	56	24	38	109	0,047-0,468
50 863-120	7318793758804	20	R3/4	G3/4	M34x1,5	65	28	36	107	0,047-0,468

TRV-2S, low flow


Article No	EAN	DN	d	D	Da	L	H	H1	H2*	KvΔT2K
50 863-510	7318793947109	10	R3/8	G3/8	M22x1,5	48	20	36	107	0,017-0,316
50 863-515	7318793947208	15	R1/2	G1/2	M26x1,5	56	24	38	109	0,017-0,316
50 863-520	7318793947307	20	R3/4	G3/4	M34x1,5	65	28	36	107	0,017-0,316

*) Valve with fitted thermostat.

Kv = m³/h at Δp = 1 bar.

KvΔT2K = The values are valid when used together with thermostatic head TRV 300.

All valves can be connected to smooth pipes by means of the KOMBI compression coupling - See catalogue leaflet KOMBI.



Reversed angle

Article No	EAN	DN	d	D	Da	L	H	H1	H2*	Kv Δ T2K
50 864-110	7318793758903	10	R3/8	G3/8	M22x1,5	48	21	47	119	0,063-0,462
50 864-115	7318793759603	15	R1/2	G1/2	M26x1,5	56	25	47	119	0,063-0,462

TRV-2S, low flow

Article No	EAN	DN	d	D	Da	L	H	H1	H2*	Kv Δ T2K
50 864-510	7318793787804	10	R3/8	G3/8	M22x1,5	48	21	47	119	0,017-0,316
50 864-515	7318793787903	15	R1/2	G1/2	M26x1,5	56	25	47	119	0,017-0,316

*) Valve with fitted thermostat.

$Kv = m^3/h$ at $\Delta p = 1$ bar.

$Kv\Delta T2K$ = The values are valid when used together with thermostatic head TRV 300.


All valves can be connected to smooth pipes by means of the KOMBI compression coupling - See catalogue leaflet KOMBI.

Accessories



Pre-setting tool

Article No	EAN
50 198-004	7318793748102



Servicing tool TRV-2, TRV-2S

When changing of valve insert during operation

Article No	EAN
50 600-005	7318793811509

Spare parts

The valve insert can be exchanged during operation - please contact TA for more information.

The products, texts, photographs, graphics and diagrams in this document may be subject to alteration by TA Hydronics without prior notice or reasons being given.

For the most up to date information about our products and specifications, please visit www.tahydronics.com.

1-5-5 TRV-2, TRV-2S 09.2013





